Alphabetical index Alphabetical index

Α	A/C (Air conditioning system)	190		Optim
	ABS (Anti-lock Brake System)	159		Radio .
	Active stabilizer suspension			Steerin
	system	159		Video
	Air conditioning system (A/C)			Automatio
	Air conditioning filter	407		system
	Automatic air conditioning			Automatio
	system	190		AVS (Ada
	Airbags			Suspens
	Airbag operating conditions	63		
	Airbag precautions for your		В	BA (Brake
	child	67		Back-up li
	Airbag warning light	450		Wattag
	Curtain shield airbag			Battery
	precautions	70		Check
	Front passenger occupant			If the ve
	classification system	72		disch
	General airbag precautions	67		Prepar
	Locations of airbags	59		befor
	Modification and disposal of			Bluetooth
	airbags	71		Brake
	Side airbag precautions	67		Fluid
	Side and curtain shield airbags			Parking
	operating conditions	63		
	SRS airbags	59	С	Care
	Alarm	54		Exterio
	Antenna	. 208		Interior
	Armrest	327		Seat be
	Ashtrays	320		Cargo ca
	Audio system			Cargo ho
	Antenna	208		CD player
	Cassette player	211		Chains
	CD player/changer	216		Child-pro
	DVD information	253		Child rest
	DVD player/changer	233		Definiti
	DVD video/audio	236		Installa
	MP3/WMA disc	224		mistalla
532				

		050
	Optimal use	
	Radio	
	Steering switches	
	Video CD	249
	Automatic headlight leveling	
	system	118
	Automatic light control system	116
	AVS (Adaptive Variable	
	Suspension System)	158
	• •	
В	BA (Brake Assist)	159
	Back-up lights	
	Wattage	508
	Battery	
	Checking	207
	If the vehicle battery is	
	· ·	400
	discharged	492
	Preparing and checking	470
	before winter	
	Bluetooth [®]	265
	Brake	
	Fluid	
	Parking brake	105
С	Care	
	Exterior	358
	Interior	360
	Seat belts	
	Cargo capacity	
	Cargo hooks	
	CD player/changer	
	Chains	
	Child-protectors	
	Child restraint system (CRS)	10
	Definition	70
	Installation	ÖI

Installing CRS with lower	Cruise control	
anchorages86	Cruise control	124
Installing CRS with seatbelts 82	Dynamic radar cruise control	127
Installing CRS with top straps 87	Cup holders	314
Child safety	Curtain shield airbags	59
Airbag precautions67	Customizable features	523
Child restraint system78		
Child-protectors18	D Daytime running light system	117
How your child should wear the seat-	Defogger	
belt36	Rear window	198
Installing child restraints81	Side mirror	
Moon roof48	Dimension	
Power window lock switch43	Dinghy towing	
Power window precautions	Display	
Removed electronic key battery	Multi-information display	113
precautions412	Touch screen	
Seat belt comfort guide34	Trip information	
Seat belt precautions37	Warning message	
Seat heater precautions 323, 325	Do-it-yourself maintenance	
Trunk24	Door courtesy lights	
Cigarette lighter321	Door pocket	
Cleaning	Doors	
Exterior358	Door lock	17
Interior360	Rear door child protector	18
Seat belts361	Driver's seat belt reminder light	
Clock318	Driving	
Coin holder313	Correct posture	57
Compass339	Procedures	9C
Condenser385	DVD player/changer	233
Console box311		
Cooling system	E Electronic key	
Engine overheating496	Replacing battery	411
	If the electronic key does not	
	operate properly	180

Emergency, in case of	Preparing and checking
lf a warning light turns on449	before winter172
If a warning message is	Engine oil maintenance data382
displayed455	EPS (Electric Power Steering) 159
If the engine will not start486	Event data recorder 447
If the shift lever cannot be	
shifted from P487 F	First-aid kit storage belt331
If the battery is discharged492	Floor mats330
lf you have a flat tire474, 476	Fluid
lf you lose your keys488	Brake386
If you think something is	Washer390
wrong445	Fog lights
lf your vehicle becomes stuck499	Switch119
If your vehicle needs to be	Wattage508
towed438	Foot light307
If your vehicle overheats496	Front passenger occupant
If the electronic key does not	classification system72
operate properly489	Front passenger's seat belt
Engine	reminder light452
Compartment376	Front seats
Hood373	Adjustment25
How to start the engine97	Driving position memory27
If the engine will not start486	Front turn signal lights
Overheating496	Wattage508
Power switch97	Fuel
Engine compartment cover378	Capacity500
Engine coolant temperature	Fuel gauge106
gauge106	Fuel pump shut off system446
Engine/inverter coolant	Gas station information542
Capacity502	Information509
Checking384	Refueling49
Preparing and checking	Fuel filler door49
before winter172	Fuel pump shut off system446
Engine immobilizer system52	Fuses413
Engine oil	
Capacity501	
Checking379	

G	Garage door opener	Intuitive parking assist136
	Gas station information542	, 3
	Gauges106	Jack
	Glove box	Positioning the jack374
		Replacing the wheel476
Н	Hands-free system262	Jack handle476
•••	Head restraints30	Jack Harlaic
	Headlight aim	V
	Headlight cleaner123	,
	Headlights	If you lose your keys488
	AFS (Adaptive Front lighting	Key number plate2
	System)117	Keys2
	Discharge headlights	Power switch
	precautions444	Mechanical key2
	Replacing light bulbs438	If the electronic key does not
	Switch116	operate properly489
	Wattage	Wireless remote control14
	Heaters	
	Seat heaters323, 325	Lexus link system343
	Side mirror198	Light bulbs
	Hill-start assist control159	Replacing438
	Hood	Wattage508
	Hooks	Light sensitive optitron meter108
	Cargo331	Lights
	Shopping bag331	Fog light switch119
	эпоррінд вадээт	Headlights switch116
		Interior lights list306
	Illuminated entry system306	Replacing light bulbs438
	I/M test	Turn signal lever104
	Indicator lights110	Vanity lights317
	Initialization	Wattage508
	Items to initialize527	
	Inside rear view mirror40	Maintenance
	Instrument panel light control107	Do-it-yourself maintenance369
	Interior lights	General maintenance365
	Interior lights308	Maintenance data498
	Wattage508	Maintenance requirements363

	Meter	Power outlet	322
	Instrument panel light control107	Power windows	43
	Meters106		
	Micro dust and pollen removal	Radar cruise control	127
	mode193	Radiator	385
	Mirrors	Radio	202
	Inside rear view mirror40	RDS (Radio Data System)	204
	Side mirror heater198	Rear sunshade	328
	Side mirrors41	Rear turn signal lights	
	Vanity mirrors317	Replacing light bulbs	438
	Moon roof46	Wattage	
	MP3 disc224	Rear view monitor system	
	Multi-information display113	Rear window defogger	
		Replacing	
0	Odometer106	Electronic key battery	411
	Oil	Fuses	
	Engine oil379	Light bulbs	438
	Opener	Reporting safety defects for	
		I	
	Fuel filler door49	U.S. owners	530
	Fuel filler door49 Hood373	U.S. owners	530
			530
	Hood373	Seat belts	
	Hood	Seat belts Adjusting the seat belt	
	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor	34
	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor (ALR)	34
	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor (ALR) Child restraint system	34
	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor (ALR) Child restraint system installation	34
	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor (ALR) Child restraint system installation	34 35
P	Hood	Seat belts Adjusting the seat belt	34 35
P	Hood	Seat belts Adjusting the seat belt	34 35 81
P	Hood	Seat belts Adjusting the seat belt	34 35 81 361
P	Hood	Seat belts Adjusting the seat belt	34 35 81 361
P	Hood	Seat belts Adjusting the seat belt	34 81 361 35 33
P	Hood	Seat belts Adjusting the seat belt	34 35 361 35 35
P	Hood	Seat belts Adjusting the seat belt	34 35 361 35 35
P	Hood	Seat belts Adjusting the seat belt Automatic Locking Retractor (ALR) Child restraint system installation Cleaning and maintaining the seat belts Emergency Locking Retractor (ELR) How to wear your seat belt How your child should wear the seat belt	34 35 361 35 33

Reminder light	452
Seat belt extenders	36
Seat belt pretensioners	34
Seat heaters32	23, 325
Seat ventilators	325
Seating capacity	171
Seats	
Child seats/child restraint	
system installation	81
Cleaning	360
Driving position memory	27
Head restraint	30
Properly sitting in the seat	57
Seat adjustment	25
Seat adjustment precautions	25
Seat heaters3	23, 325
Ventilated seats	325
Service reminder indicators	111
Shift lever	
If the shift lever cannot be	
shifted from P	487
Transmission	100
Shift lock system	487
Shopping bag hooks	331
Side airbags	59
Side marker lights	
Switch	116
Side mirror	
Adjusting and folding	41
Driving position memory	27
Smart access system with	
push-button start	
Antenna location	6
Entry function	4
Starting the hybrid system	97
Spare tire	
I.	
Inflation pressure	506

Spare tire	477
Spark plug	502
Specifications	498
Speedometer	106
Steering wheel	
Adjustment	39
Audio switches	262
Driving position memory	27
Storage compartment	313
Storage feature	310
Stuck	
If your vehicle becomes stuck	499
Sun visors	316
Switch	
Fog light switch	119
Lexus link system switches	343
Light switches	116
Mode select switch	101
Power door lock switch	17
Power switch	97
Power window switch	43
Window lock switch	43
Wipers and washer switch	120
Tail lights	

П	l ail lights
	Switch116

Theft deterrent system	
Alarm	54
Engine immobilizer system	52
Theft prevention labels	56
Tire inflation pressure	506
Tire information	
Glossary	519
Size	516
Tire identification number	514
Uniform tire quality grading	517

Tires	V	Vanity lights	
Chains	174	Vanity lights	317
Checking	391	Wattage	508
Compact spare tire	477	Vanity mirrors	317
If you have a flat tire47	4, 476	VDIM (Vehicle Dynamics	
Inflation pressure	506	Integrated Management)	160
Information	512	Vehicle identification number	499
Pressure warning system	391	Vehicle load limits	171
Replacing	476	Ventilators	325
Rotating tires	391	VGRS (Variable Gear Ratio	
Size	506	Steering)	159
Snow tires	175	VSC (Vehicle Stability Control).	159
Tools	476		
Total load capacity	171 W	Warning buzzers	
Touch screen	180	Brake system	449
Towing		Downshifting	103
Dinghy towing	178	Open door	451
Emergency towing	439	Seat belt reminder	452
Trailer towing	177	Warning lights	
TRAC (Traction control)	159	Anti-lock brake system (ABS)	451
Transmission		Brake system	449
If the shift lever cannot be		Charging system	450
shifted from P	487	ECB/VSC (Electronically	
Mode select switch	101	Controlled Brake System/	
S mode	102	Vehicle Stability Control)	451
Transmission	100	Electric power steering	
Trip meter	107	warning light	451
Trunk		Low fuel level	451
Extending a space	332	Malfunction indicator lamp	450
Opener	21	Master warning light	452
Trunk light	23	Open door	451
Wattage	508	Pre-collision system	451
Turn signal lights		Seat belt reminder light	452
Replacing light bulbs	438	SRS airbags	450
Switch	_	Tire pressure warning light	452
Wattage	508		

Warning messages
Anti-lock Brake System (ABS)460
Brake Assist (BA)460
Dynamic radar
cruise control458
Engine oil level463
Engine oil maintenance464
Engine oil pressure456
Headlight456
Hill-start assist control460
Hood462
Intuitive parking
assist458, 465, 470
Moon roof463
Open door462
Parking brake463
Pre-Collision System 458, 465
Rear lights system457
Smart access system with
push-button start471
Steering lock457, 473
Tire pressure warning
system456, 464
TRAC (Traction control
system)460
Trunk463
VGRS (Variable Gear Ratio
Steering)461
VSC (Vehicle Stability Control
system)460
VSC/ECB (Vehicle Stability
Control/Electronically Controlled
Brake system)460
Washer fluid463

Washer	
Checking	390
Preparing and checking	
before winter	172
Switch	
Washing and waxing	
Weight	
Cargo capacity	168
Load limits	171
Weight	498
Wheels	
Window glasses	43
Window lock switch	43
Windows	
Power windows	43
Rear window defogger	
Washer	
Windshield wipers	
Position	174
Windshield wipers	120
Winter driving tips	172
Wireless remote control	
Locking/Unlocking	14
Replacing the battery	
WMA disc	